

Assembly Instruction For 21153

- 1. Put the nipple into coupler, then secured by hex nut
- 2. Place the notch cap1, cap1, tube and cap2 on the nipple, then secured by loop
- 3. Place the notch cap2 on the nipple 1, then seured by finial
- 4. Place the fabric shade on the socket, then secured by socket ring
- 5. Put the etched shade on the fabric shade

