

POST INSTALLATION

PRIOR TO INSTALLATION CHECK WITH LOCAL AUTHORITIES FOR LOCATION OF UTILITY LINES (GAS, ELECTRIC, WATER) IN THE AREA WHERE YOUR HOLE WILL BE DUG.

MAKE SURE ALL UNDERGROUND WIRING HAS BEEN INSTALLED ACCORDING TO LOCAL BUILDING CODES.

1. Dig a hole 16" in diameter. Check with local building codes for hole depth.
2. Layer the bottom of the hole with 4" of gravel or crushed stone. Paint the lower section of the pole that will be buried with an asphalt sealer. This will prevent the corrosion between the pole and concrete.
3. Place the pole in the center of the hole and feed the wire through the wireway hole. Use stakes and twine to support the pole and keep it level.
4. Mix and pour concrete per the manufactures instructions, and let the concrete dry completely

