artos®

F901-19

6" shower rainhead squ

BRUSHED NICKEL(BN)



BLACK(BK)



CHROME(CH)



INSTALLATION GUIDE

artos®

F901-19

U

6" shower rainhead squ

OPERATING SPECIFICATIONS



FEATURES Solid Brass

OPERATING PRESSURE

Minimum: 15 psi Maximum: 75 psi Above 90psi it may be necessary to install a pressure reducer

OPERATING TEMPERATURE Maximum: 176°

FLOW RATE

APPROVALS




PRODUCT DIMENSIONS

6" shower rainhead squ

F901-19

artos®



| ← 5_3/4" | | | | | | | | | | | |
|-----------------|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | | | | | | |
| 0 | ۲ | 0 | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ٥ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ٥ | ۲ | ۲ | ۲ | ٥ | ۲ | ۲ | ۲ | • |
| ٥ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | • |
| 0 | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | ۲ | 0 |
| | | | | | | | | | | | |


© 2018 ed. All technical and pricing information is subject to change without prior notice. To confirm accuracy check with Artos customer service.

artos

F901-19

6" shower rainhead squ

INSTALLATION STEPS




PARTS BREAKDOWN

6" shower rainhead squ

F901-19

artos



- (1) SWIVEL ARM SECURING NUT
- (2) SWIVEL ARM
- (3) SHOWER HEAD SCREWS
- (4) SHOWER HEAD TOP
- (5) RUBBER MATRIX
- (6) SHOWER HEAD BOTTOM

WESTOVER, INC 13305 B STREET OMAHA, NEBRASKA 68144 WWW.ARTOS.US.COM

© 2018 ed. All technical and pricing information is subject to change without prior notice. To confirm accuracy check with Artos customer service.

CARE & MAINTENANCE

artos[®]

6" shower rainhead squ

For best results, keep the following in mind to retain the high quality finish of your $artos^{\circ}$ faucets:

- •Use a soft, dampened sponge or cloth. On no account should you use an abrasive material such as a brush, scouring pad or steel wool to clean surfaces.
- Test your cleaning agent solution on an inconspicuous area before applying to the entire faucet.
- •Wipe surfaces clean and rinse completely with water immediately after applying cleaning agent.
- An ideal cleaning technique is to rinse faucet thoroughly and blot dry any water from the surface after each use.

LIMITED LIFETIME WARRANTY

$arcos^{\circ}$ faucets are guaranteed for life against leaks and finishing defects for as long as the original purchaser owns it.

Damage caused by accident, misuse, abuse, improper installation, improper cleaning or alteration will void the warranty. This warranty does not cover replacement parts where damage is caused by normal wear and tear. Westover, Inc is not responsible for labor charges, installation or other incidental or consequential costs. Proof of purchase must be provided with all claims.

Please register this product online at WWW.ARTOS.US.COM

ITEM NO. **F901-19** SERIAL NO.