

14001

INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions as you may need them a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N. E. C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.


ASSEMBLY AND INSTALLATION(Portable)

1. Drill the holes in the drywall using the drill with appropriate size drill bit.
2. Use a Phillips Screwdriver to insert the Wall Anchors at the marked keyhole locations.
3. Lift the lighting fixture against the wall so that the two key holes located on backplate align with and engage the protruding Wall Screws heads.
4. Install tube and tube with plug to the backplate.
5. Unscrew the socket ring from socket. Set shade onto socket and secure with socket ring.
6. If needed, please slowly loosening the knob and hold the short tube to adjust the light and socket to the desired angle, then tighten the knob clockwise until secure.
7. Install bulb: (bulb not included)

(Don't exceed the maximum capacity recommended on the Sockets).

8. Insert plug into electrical outlet.

Note: This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug. Do not attempt to defeat this safety feature.



ASSEMBLY AND INSTALLATION(Hardware)

1. Secure the Round mounting bar to the outlet box with the box screws.
2. Cutting the cord so that they are at least 6 inches (152.4 mm) long within an outlet box. Unscrew the tube and tube with plug from the backplate. Add the cap onto the hole of the tube.
3. Pull out the wires and ground wire from the Outlet Box. Untie the wire nuts.
Make wire connections with Wire nut:
 - White wire from light to White Wire from power source.
 - Black wire from light to Black Wire from power source.
 - Attach the Ground Wire to Round Mounting bar with a Green Screw.
4. Align the Back plate to the Outlet box, then secure it to the Round mounting bar with the ball nuts.
5. Unscrew the socket ring from socket. Set shade onto socket and secure with socket ring.
6. If needed, please slowly loosening the knob and hold the stem to adjust the socket to the desired angle, then tighten the knob clockwise until secure.
7. Install bulb: (bulb not included)
(Don't exceed the maximum capacity recommended on the Sockets).

INSTALLATION IS NOW COMPLETED

